

MICRO MOBILITY FIRE WORKSHEET

Life Safety

- Wear full PPE.
- Rescue/Check for victims.
- Evacuate / Shelter In Place.

Incident Stabilization

○ If outdoors

- Allow micro mobility to burn to completion
- Prevent propagation to other devices/battery packs
- Request HIRT to assist with battery stabilization, mitigation, overpacking, and disposal.

○ If indoors/structure fire considerations

- Attack the residential fire like normal
- If in an enclosed space, explosive atmospheres are possible.
- Remove the involved micro mobility device from structure, if possible.
- **Move ALL Lithium-Ion Batteries (cells, batteries, etc.) and devices to a safe location, away from firefighting operations PRIOR to initiating overhaul**
 - During fire operations uninvolved batteries and devices may ignite behind you, underneath you, or all around you.
 - Use shovel with wooden handle (DO NOT USE HANDS OR POCKETS)
 - Outside is preferred
 - If not possible, consider a bathroom, bathtub, sink or metal bucket and fill with water.
 - Ensure ventilation (i.e. hydraulic) is provided for enclosed areas such as small bathrooms.

○ Overhaul

- Wear full PPE including donned SCBA!
- Request HIRT to assist with battery stabilization, mitigation, overpacking, disposal, and civilian guidance.
- Assist HIRT in removing all batteries from structure.
- Provide protection line during HIRT overpacking procedures.